

TransMORGrifier ©

LEVEL This controls the output level of the pedal

RELEASE This controls how quickly the compressor stops compressing the signal. Short time turn left, long time turn right.

ATTACK This controls how quickly the compressor starts compressing the signal. Short time turn left, long time turn right.

RATIO This controls how much the pedal compresses the signal. Little compression turn left, much compression turn right.

POWER REQUIREMENTS the pedal uses a standard 9V battery located inside. Or you can use a 9V DC external power supply with a 2.1mm DC plug. Center is negativ (-).

Sample settings

"CLASSIC COUNTRY"



Level



Release



Attack



Ratio

"JAZZ"



Level



Release



Attack



Ratio

"BLUESY THICK"



Level



Release



Attack



Ratio

"NUKE-HEAVY EFFECT"



Level



Release



Attack



Ratio